

מתקן נגיש למשחק באולינג (ניתן לקיפול)

הוראות שימוש:

1. יש לפרק את המתקן או להרכיבו באזור רחוב ופני מריהיטים והרחק מאנשים אחרים העולמים להיפגע בעת ההרכבה/ הפירוק.
2. בעת הכנסת הפין למקום החיבור חשוב להקפיד שהיד לא תיתפס בו.
3. יש להניח את השיפוע מאחוריו מסלול ה'באולינג', כך שקצתה השיפוע התחתון צמוד למיסילה.

השימוש במתקן באחריות הבלעדית של המשתמש/המטפל/ההוראה

جهاز قابل للطي "للبولينج".

إرشادات الاستخدام:

1. يجب تفكيك الجهاز أو تجميجه في منطقة واسعة خالية من الأثاث وبعيداً عن الأشخاص الآخرين الذين قد يتعرضون للإصابة أثناء التجميغ / التفكيك.
2. من المهم التأكد عند إدخال المسamar في مكان التوصيل أن اليد ليست عالقة به.
3. يجب وضع المنحدر خلف صالة البولينج، بحيث يكون قاع المنحدر السفلي قريباً من المسار.

تقع مسؤولية استخدام الجهاز فقط على المستخدم / المعالج / الوالد

Foldable device for bowling

Instructions for use:

1. The device should be disassembled or assembled in an open area free of furniture and away from other people who may be injured during assembly/disassembly.
2. When inserting the pin into the connector, it is important to make sure that the hand is not caught inside.
3. The slope should be placed behind the bowling alley, so that the lower end of the slope is close to the track.

The use of the device is under the sole responsibility of the user / caregiver / parent