פל"א
פתרונות לילדים,
מבית אלי"ן

אוגוסט 2021

ידיות אחיזה לכוס גמישה

ילדים המשתמשים בכוס גמישה-פלקסיקאפ בהמלצת מטפל יכולים להיעזר גם בידיות החיצוניות שמקלות על הבאת הכוס לפה.

הוראות שימוש:

1. יש להדק את הידיות לתחתית הכוס ולוודא שהחיבור יציב.
2. לא מיועד לשתייה חמה.
3. בכל מקרה של פגם אין להשתמש במוצר.

השימוש במוצר באחריותו הבלעדית של המשתמש/ המטפל/ ההורה

مقابض خارجية للمساعدة في إمساك وإمالة كأس مرن خاص (Flexi Cup)، وهي مقابض مخصصة للأطفال الذين يعانون من محدودية في حركة الرقبة أو صعوبة في الإمساك.

إرشادات الاستخدام:

١. قم بربط المقابض في الجزء السفلي من الكأس وتأكد من ثبات التوصيل.

٢. غير مخصص للمشروبات الساخنة.

٣. في حال وجود عيب يحظر استخدام المنتج.

ان استخدام المنتج يعتبر المسؤولية الوحيدة والحصرية للمستخدم/المعالج/الوالد

External handles for easier grip and tilt of a special flexible cup (Flexi Cup), intended for children with limited movement of the neck or grip difficulties.

Instructions for use:

1. Tighten the handles to the bottom of the cup and ensure stable connection.
2. Not intended for hot liquids.
3. Avoid using the product if damaged.

The use of the product is under the sole responsibility of the user / caregiver / parent